

**ANOTHER
INNOVATIVE,
HIGH-QUALITY,
COST-SAVING
PRODUCT FROM
SP PRODUCTS**

"Quick Pipe" Block

**A new solution to save labor
while preventing damage
to roof membrane**

Strong, lightweight one-piece construction avoids hauling and cutting of treated lumber, and the foam base prevents damage to roof membrane as attached pipes expand and contract during temperature changes.

**NECA
1999
SHOWSTOPPER**



**Fast, On-Time Delivery –
24 hours a day, 365 days a year!**

- **High density Polyethylene Resin** resists UV for 25 years and withstands up to 185°C temperature.
- **Extremely lightweight and strong one piece construction.** Avoid cutting heavy 4x4 treated lumber, hauling lumber to jobsite and up to roof reducing chance for injury.
- **Allows longer life quality job.** Yellow certifoam base of the block prevents damage to the roof membrane whereas conventional pressurized lumber grinds into membrane when attached pipes expand and contract during temperature changes, eventually wearing through membrane.
- **Requires less man hours and supervision.** Allows more man hours to be spent on complicated work.

S P E C I F I C A T I O N S

Cat. #	Description	Quantity Per Box	Weight Each
QPB2000	Quick Pipe Block	25	.8 lbs.

Terms: 2% 10 Days, Net 30 Days. F.O.B. Factory - Elk Grove Village, Illinois. Freight allowed to one destination on 1,000 lbs. Quick Pipe Blocks in U.S.A. For Alaska, Hawaii, Puerto Rico and elsewhere consult factory. Freight allowed on shipment of any quantity of Quick Pipe Blocks if combined with any other SP items to make a freight allowed shipment, provided the entire order is released for one shipment to one location.

Recommended Installation

Hardware	Pipes per Block	Spacing per Uniform Mechanical Code (UMC)
½" straps oversized	4 - ½" pipes	6'
by one diameter with	4 - ¾" pipes	8'
#8 x ½" zip screw	3 - 1" pipes	8' or 10'
	3 - 1¼" pipes	10'
	2 - 1½" pipes	10'

Quick Pipe Blocks should be freestanding (not attached to the roof) and are ideal for usage on all current types of built-up and single-ply roofing membranes. For built-up roofs, remove loose aggregate from area under the Quick Pipe Block, then set the block with pad directly on the membrane. Finally, backfill around the pad with aggregate.

**To place an order, or to request samples and our full-line catalog,
call toll-free at 1-800-233-8595**

**For competitive prices on this or any of our other High-Quality, Cost-Saving Products
contact our distributor or representative in your area.**

And remember our fast, On-Time Delivery – 24 hours a day, 365 days a year!

SP PRODUCTS, INC.
Productivity and value thru ideas

1-800-233-8595

